

CPC464/664/6128 ASCII Table

ASCII Table


	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
1	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
2	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
3	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
4	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
5	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
6	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
7	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
8	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
9	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
A	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
B	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
C	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
D	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
E	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐
F	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐	☐

Hex to Dec to Hex Look-up Table

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	16	32	48	64	80	96	112	128	144	160	176	192	208	224	240
1	1	17	33	49	65	81	97	113	129	145	161	177	193	209	225	241
2	2	18	34	50	66	82	98	114	130	146	162	178	194	210	226	242
3	3	19	35	51	67	83	99	115	131	147	163	179	195	211	227	243
4	4	20	36	52	68	84	100	116	132	148	164	180	196	212	228	244
5	5	21	37	53	69	85	101	117	133	149	165	181	197	213	229	245
6	6	22	38	54	70	86	102	118	134	150	166	182	198	214	230	246
7	7	23	39	55	71	87	103	119	135	151	167	183	199	215	231	247
8	8	24	40	56	72	88	104	120	136	152	168	184	200	216	232	248
9	9	25	41	57	73	89	105	121	137	153	169	185	201	217	233	249
A	10	26	42	58	74	90	106	122	138	154	170	186	202	218	234	250
B	11	27	43	59	75	91	107	123	139	155	171	187	203	219	235	251
C	12	28	44	60	76	92	108	124	140	156	172	188	204	220	236	252
D	13	39	45	61	77	93	109	125	141	157	173	189	205	221	237	253
E	14	30	46	62	78	94	110	126	142	158	174	190	206	222	238	254
F	15	31	47	63	79	95	111	127	143	159	175	191	207	223	239	255

CPC464 Keyboard

CPC464 Keyboard: Layout




CPC464 Keyboard: Characters




Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers


JOYSTICK 0




JOYSTICK 1



CPC464 Keyboard: ASCII Codes




Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers



52 55
4E 22
0D

CPC664 Keyboard

CPC664 Keyboard: Layout




CPC664 Keyboard: Characters




Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers


JOYSTICK 0





JOYSTICK 1



CPC664 Keyboard: ASCII Codes



Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers




5255
 4E22
 0D

CPC6128 Keyboard


CPC6128 Keyboard: Layout



JOYSTICK 0



JOYSTICK 1




CPC6128 Keyboard: Characters




Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers

JOYSTICK 0



JOYSTICK 1




CPC6128 Keyboard: ASCII Codes


1B 66	21 64	22 65	23 57	24 56	25 <u>49</u>	26 <u>48</u>	27 41	28 40	29 33	5F 32	3D 25	A3 24	10 16	7F 79	37 10	38 11	39 3	
1B 1B	31	32 7E	33	34	35	36	37	38	39	30 1F	2D	5E 1E	10 10	7F 7F	37 37	38 38	39 39	
09 68	51 67	57 59	45 58	52 <u>50</u>	54 <u>51</u>	59 43	55 42	49 35	4F 34	50 27	7C 26	7B 17	0D 18	34 20	35 12	36 4		
09 E1	71 11	77 17	65 05	72 12	74 14	79 19	75 15	69 09	6F 0F	70 10	40 00	5B 1B		34 34	35 35	36 36		
	70	41 69	53 60	44 61	46 <u>53</u>	47 <u>52</u>	48 44	4A 45	4B 37	4C 36	2A 29	2B 28	7D 19		31 13	32 14	33 5	
	61 01	73 13	64 04	66 06	67 07	68 08	6A 0A	6B 0B	6C 0C	3A	3B	5D 1D	0D 0D	31 31	32 32	33 33		
	21	5A 71	58 63	43 62	56 55	42 54	4E 46	4D 38	3C 39	3E 30	3F 31	60 22		21	30 15	F4 0	2E 7	
	7A 1A	78 18	63 03	76 16	62 02	6E 0E	6D 0D	2C	2E	2F	5C 1C			30 30	F0 F0	2E 2E		
	23	E0 9	20											47	0D 6	F6 8	F5 2	F7 1
	E0 E0	20												0D 52 55 4E 22 0D	F2 FA	F1 F9	F3 FB	

Black : Specified key (bottom)
 Shift + specified key (top)
Blue : Control + specified key
Red : Key number
 Underlined key numbers have equivalent keyboard & joystick 1 key numbers

JOYSTICK 0



JOYSTICK 1



Made by ...

Bert Post Uiterweer

Long-time lover of the

Amstrad Arnold CPCComputer (the poor man's Macintosh),

and of the

Apple Macintosh Computer (the rich man's Arnold).

baajt@wishmail.net